




BT-861

RADIO AM/FM



MANUAL DE INSTRUCCIONES

USO DE LA RADIO

INSTALACIÓN DE LA BATERÍA

Abra la tapa de las pilas e inserte 2 x AAA / UM4 baterías de acuerdo con el diagrama de polaridad impresas en el compartimiento de la batería.

ENCENDER/APAGAR LA RADIO Y AJUSTAR EL NIVEL DE VOLUMEN

Use el selector [ON/OFF/VOLUME] para encender el aparato y ajustar el volumen.

ESCUCHAR BANDA DE FM

Al escuchar emisiones de FM, extienda completamente la antena telescópica y pulse el interruptor [FM / AM] a la ubicación de FM, a continuación, gire el mando [TUNING] para seleccionar la emisora deseada.

ESCUCHAR BANDA AM

Para escuchar AM, pulse el interruptor [FM / AM] hacia AM, a continuación, gire el [TUNING] para seleccionar la emisora que desee AM.

ESCUCHA A TRAVÉS DE AURICULARES /
ALTAVOZ

Auriculares: Reducir el nivel del volumen, a continuación, insertar los auriculares en el conector de auriculares.

Altavoz: La unidad cambiará al sonido por altavoces automáticamente al desconectar los auriculares.

PRECAUCIONES

No exponga la radio a los rayos solares, próxima de fuentes de calor, ni lo deje en lugares con mucho polvo o donde pueda sufrir golpes mecánicos.

No exponga la radio a ambientes húmedos.

Durante tormentas eléctricas, no encienda la unidad durante su estancia en el exterior.

No utilice líquidos abrasivos para limpiar el aparato, límpielo con un paño suave humedecido con agua.

Si el sonido es bajo o distorsionado, cambie todas las pilas por otras nuevas.

No mezcle baterías usadas con las nuevas.

Si la unidad no se usa durante un tiempo prolongado, retire las pilas para evitar fugas o corrosión.

"Las especificaciones pueden cambiar sin previo aviso"

IMPORTADO

I.R.P., S.L.

AVDA. SANTA CLARA DE CUBA 5

SEVILLA, SPAIN



DECLARACIÓN DE CONFORMIDAD

I.R.P., S.L. declara bajo su responsabilidad que el aparato indicado cumple los requisitos de las siguientes directivas:

DIRECTIVAS EMC

EN55013:2001+A1:2003+A2:2006

EN55020:2007+A11:2011

Descripción del aparato:

Modelo BRIGMTON **BT-861**

Radio con altavoz incorporado

Importador: I.R.P., S.L.

Dirección: Avda. Santa Clara de Cuba 5, 41007,
Sevilla.



BT-861
AM/FM RADIO



OPERATION MANUAL

USING THE RADIO

BATTERY INSTALLATION

Open the battery cover and insert 2 x AAA / UM4 batteries according to the polarity diagram imprinted on the battery compartment.

TURN ON / OFF THE RADIO AND ADJUST THE VOLUME LEVEL

Dial the [ON / OFF / VOLUME] knob downwards to turn on the unit and adjust the volume level.

LISTENING TO FM BAND

When listening to FM broadcasting, fully extend the telescopic antenna and push the [FM / AM] band switch to FM location, then rotate the [TUNING] knob for your desired FM station.

LISTENING TO AM BAND

When listening to MW broadcasting, push the [FM / AM] band switch to AM location, then rotate the [TUNING] knob for your desired AM station. As the internal ferrite bar functions as the antenna for AM

reception, you may rotate the unit for better reception.

LISTENING VIA EARPHONES / SPEAKER

Earphones listening: Reduce the volume level, then insert the earphones into the earphone jack for listening.

Speaker listening: The unit will switch to speaker sound automatically when you disconnect the earphones from the unit.

PRECAUTIONS

- Do not expose the radio to sunlight, place in the proximity of heat sources, or leave it in places with excessive dust or mechanical shocks.
- Do not expose the radio to rain and humid environments.
- During thunderstorms, do not turn on the unit while staying outside.
- Do not use any abrasive powder to clean the cabinet, wipe it with a soft cloth moistened with mild soap and water.
- If the sound becomes low or distorted, replace all the batteries with new ones. Do not mix old and new batteries together.
- If the unit is not used for a long time, remove all the batteries to prevent battery leakage or corrosion.

"Features can change without notice"

IMPORTED

I.R.P., S.L.

AVDA. SANTA CLARA DE CUBA 5

SEVILLA, SPAIN



DECLARATION OF CONFORMITY

I.R.P., SL declare under our responsibility that the equipment meets the requirements indicated in the following directives:

EMC DIRECTIVES

EN55013:2001+A1:2003+A2:2006

EN55020:2007+A11:2011

Description of apparatus:

BRIGMTON Model **BT-861**

Radio with built-in speaker

Importer: I.R.P., SL

Address: Avenida Santa Clara de Cuba 5, 41007,
Sevilla.

V.042813